



BOX CALIPER



The solid board and corrugated fibreboard packages meet the modern requirements of low cost, high performance, minimal environment impact and addition of value to the packed goods.

The internal dimensions of these packages are fundamental to the preservation of the goods wrapped during transportation, storage and handling.

The C-INT is used by manufacturers and end-users to control quickly and with absolute precision these internal dimensions, reducing the risk of possible future losses caused by products out of specification.

The C-INT is extremely light and easy to handle.

The mechanical construction ensures long operation periods with minimal maintenance requirements.

Two parallel plates are mounted on a high precision telescopic shaft, that ensures perfect parallelism within all the measuring range and that is easily adjustable in 2 stages:

- in the first stage a rough adjustment is done by means of a scale integrated to the telescopic shaft with resolution 1 cm
- in the second stage a fine adjustment is done by means of a vernier integrated to the telescopic shaft with resolution 1 mm.

Technical specifications

- Resolution for all sizes
1 mm

Physical specifications

- Net Weight
1.25 to 2.5 kg according to size

Features

Available in several size:

- XS - 100-170 mm
- S - 120-200 mm
- M - 200-350 mm
- L - 350-650 mm
- XL - 650-1200 mm